Cat. No. 17-855

Wireless Phone Recording Controller

This RadioShack Wireless Phone Recording Controller is specially designed to let you use your portable recorder to record important conversations through your cellular phone's headset jack. **Note:** A headphone/microphone headset is required to operate this adapter. It is not supplied but several models are available at your local RadioShack store.

Installing Batteries

The controller requires two AAA batteries (not supplied) for power.

Cautions:

- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- If you do not plan to use the controller for a month, remove the batteries. Batteries can leak chemicals that can destroy electronic parts.

Slide off the battery compartment cover and install two AAA batteries according to the polarity symbols + (positive) or – (negative) marked inside of the compartment.

When the POWER/LOW BATT indicator does not light or the controller stops operating properly, replace the batteries.

Warning: Dispose of old batteries promptly and properly. Do not burn or bury them.

Connection

(Illustration) ***Please add a callout to the headset jack, tape recorder, headset, and wireless phone.***

Note: Wireless phone, headset, and tape recorder are not supplied.

1. Insert the recording controller's 3/32-inch (2.5 mm) stereo plug into the cellular phone's headset jack.
2. Insert the recording controller's 1/8-inch (3.5 mm) mono plug into the recorder's **MIC IN** jack.
3. Plug your headset (required, not supplied) into the recording controller's 3/32-inch (2.5 mm) headset jack.

Operation

Important: Every state has different regulations governing the recording of conversations over the telephone. Be sure to check your local, state and federal laws before using this product to record any telephone conversation in order to determine that your use is in compliance with such laws or guidelines.

1. Slide **ON/OFF** to **ON**. The POWER/LOW BATT indicator lights.

   Note: When the battery power becomes weak, the POWER/LOW BATT indicator flashes. Replace the old batteries with new ones.

2. Turn on your recorder and start recording while you are using the headset.
3. To save battery power, always turn the power off when you are not using the recording controller.